

- Nozzles and Pipes -

Always cut pipes with a rotary pipe cutter and deburr the inside of the tube this will prepare the pipe for fitting to the connectors which are all push in. Ensure all push in fittings are fully inserted into the fitting.

Your system is supplied with 6 nozzles, A minimum of 2 must be fitted in the cockpit. A minimum of 3 should be fitted to the engine bay, **ALL 6 NOZZLES MUST BE USED**. It is recommended that a vehicle with a turbocharger, 4 nozzles are fitted to the engine bay 2 on the inlet system and 2 on the Turbocharger plus 2 in the cockpit. On normally aspirated engines 3 in the cockpit and 3 in the engine bay. Never point the nozzles directly at the face or upper body.

- Maintenance -

Ensure the pressure gauge is in the green. Visual inspection of all components for damage, including nozzles tubes and cylinder, ensure cables are well lubricated with grease.

Every 2 years the system must be returned to for service and revalidation. As this system has a stainless-steel cylinder, this system has a 16 year safe working life.

- Replacement Pipe , Fittings and Nozzles -

Additional or replacement pipes fittings and nozzles are available from PD Extinguishers or its authorised agents.



PD Extinguishers

Revidge Fold

Revidge Road

Blackburn

BB1 8DJ

+44 (0)254 954954

info@pdextinguishers.co.uk

www.pdextinguishers.co.uk

Revision 1




AFFF Fire Extinguishing System

Mechanical Operation

Installation & Maintenance Instructions



Thank you for purchasing a PD Extinguishers System, this extinguisher is designed to suppress fire in a competition saloon car, giving the occupants of the car time to exit the vehicle to safety. This system complies with its FIA Homologation only when installed in its entirety.



- System Components -

1 x Cylinder with Valve	2 x Rolls of Pipe	4 x Cone Nozzle
2 x Cable Nipples	1 Tee Pipe Fitting	2 x Pull Cables
1 x Instruction Manual	2 x Flat Spray Nozzles	2 x E Stickers
2 x Bracket including Straps	4 x Tee Nozzle Fittings	
2 x 90° Nozzle Fittings	8 x M6 Bolts Nuts and Washers	

- Mounting the Cylinder -

Your cylinder should be mounted within the cockpit, it is best mounted to allow easy checking of the pressure gauge and service record. Attach the brackets to the vehicle floor with a min of 8 (4 in each bracket) M6 bolts nuts and washers. When securely bolted and the straps are tight, no longitudinal movement will occur, however, longitudinal support can be added or the unit may be mounted between sill and tunnel or other supporting structures.

- Extinguishant and Ingredients -

Contact with the skin: Take off contaminated clothing immediately. Wash the areas of the body that have come into contact using plenty of running water and soap. **Contact with eyes:** Wash immediately and plenty with running water with open eyelids for at least for 10 minutes, then protect your eyes with sterile gauze or clean cloth. Seek medical advice if irritation continues. **Inhalation:** clear the air of the ambient. Remove quickly the subject from the contaminated atmosphere and keep them in ventilated atmosphere. In case of malaise, consult a doctor. **Ingestion:** Not induce vomit. Immediately take medical advice showing this information following.

Ingredients:

Name	Product identifier	%	Classification according to Regulation (EC) No. 1272/2008 [CLP]
Ethane-1,2-diol	(CAS-No.) 107-21-1 (EC-No.) 203-473-3 (EC Index-No.) 603-027-00-1 (REACH-no) 01-2119456816-28	1.5 to 3	Acute Tox. 4 (Oral), H302 STOT RE 2, H373
2-(2-Butoxyethoxy)ethanol	(CAS-No.) 112-34-5 (EC-No.) 203-961-6 (EC Index-No.) 603-096-00-8 (REACH-no) 01-2119475104-44	0.24 to 0.6	Eye Irrit. 2, H319
2-methyl-2,4-pentanediol substance with a Community workplace exposure limit	(CAS-No.) 107-41-5 (EC-No.) 203-489-0 (EC Index-No.) 603-053-00-3 (REACH-no) 01-2119539582-35	0.0 03 - 0.006	Skin Irrit. 2, H315 Eye Irrit. 2, H319

Mechanical Cable Actuation -

Pull Cables should be mounted to prevent tight bends or kinking of cables. Drill a 12mm hole in the panel where the cable is to be mounted, take care to ensure the panel is sufficiently strong to prevent panel deforming, place reinforcement behind if required. 1 to be mounted externally below the windscreen 1 to be mounted internally in easy reach of both occupants (if applicable) Please lubricate cables with grease and check regularly for free operation. Fit the cable to the valve as indicated in Figure 1, allow 6 to 12mm clearance to the nipple. Fit the Stickers adjacent to the Pull to identify the location.




Figure 1